

**STEP 1:**

Slide the Roll Gate Adapters onto the bottom Connector Pins attached to the Roll Gate. Secure the Gate Adapters to the Roll Gate by sliding the top Connector Pins into the tops of the square tubes as shown in figures 1 and 2.

**STEP 2:**

Using figure 3 as a reference. Remove the two bolts on the outside tube of the Alley Bow. Slide the Alley Bow up to the Roll Gate Adapters and slide the square tube over the bottom Connector pin attached to the Alley Bow. Slide the top Connector Pin into the square tube.

Secure the other side together, by placing the two screws through the two slots on the Roll Gate Adapter that align with the holes on the alley bow and replace the nut as shown in figure 3.

